



Instructions:

1. Determine the side of door to which the bolt is to be applied.
2. Drill and tap mounting holes in door for the bolt.
See drawing (A) for top bolt or drawing (B) for bottom bolt preparation.
3. Disassemble the guide from bolt by sliding guide out of the bolt.
4. Attach the bolt guide to the door.
5. Slide the bolt over the guide which is attached to the door.
6. Insert end-plug into the bolt.
7. Insert end-plug stud through the end of the bolt and end-plug.
8. Select wither bottom or top strike.
9. Align strike with bolt and attach.

Caution:

Hollow metal door & frame should be properly reinforced with a plate at least 3/16" (5) thick.

NOTE: Dimensions in () are in millimeters.

	QTY	SCREW DETAILS
BOLT GUIDE (STANDARD)	3	12-24 x 1" FHMSF
	3	#12 x 1 1/4" FHWSP
STRIKE	2	12-24 x 1" FHMSF
	2	#12 x 1 1/4" FHWSP
	2	PLASTIC EXP. SHIELD